



INSTALLATION PROCEDURE

SURFACE MOUNT/RETROFIT TILES

Inline Dome Pattern

View additional photos, drawings and specifications on our website: www.adawalkways.com
Call 866-339-5401 with any questions

◆ **Be sure to read & understand all of these instructions before you begin.**

- A. The installation area should be cleaned of all debris, oil, grease, and laitance: and that the area is completely free of moisture.
- New Construction: GC should create a ¼” deep recess as part of the concrete pour.
 - Existing Construction: Tile may be surface mounted on existing curb ramp with no surface preparation.
- B. Lay out the tiles on the substrate as they will appear when installed.
- If required, the tile may be cut using a table saw and carbide tipped blade.
- C. Place a ⅜” bead of adhesive on the frame of the bottom of each tile.
- Each 30 oz. Tube should yield approximately 16 square feet of coverage.
- D. Set the tile in the installation area. Make all necessary adjustments prior to fastening.
- E. Fasteners shall be installed in pre-formed fastener locations. Holes shall be drilled using a hammer drill with ¼” x 2” min SDS bits. The drilled holes must be a minimum of 1 ½” deep. Place fasteners in hole and hammer into place.
- If additional fasteners are required, use a ½”, six point, 82 degree countersink to add a new fastener location. Follow same drilling method for installing the fastener.
- F. Caulk around perimeter of entire installation using Sonneborn NP1 or equivalent.
- All concrete dust present on the tile from the drilling process must be cleaned off of the tile face prior to using any caulking materials.
- G. Following completion of the installation, all surfaces of the work shall be cleaned to the satisfaction of the Engineer/Owner.

PRODUCT SIZES 24”x24”, 24”x36”, 24”x48”, 24”x60”, 36”x36”, 36”x48”, 36”x60”

APPLICATION Retrofit Cured Concrete Handicap Ramps or Platforms