



INSTALLATION PROCEDURE

CAST-IN-PLACE COMPOSITE PAVER TILES

Inline Dome Pattern

View additional photos, drawings and specifications on our website: www.adawalkways.com
Call 866-339-5401 with any questions

◆ **Be sure to read & understand all of these instructions before you begin.**

- A. The physical characteristics of the concrete shall be as specified in the Contract Documents while maintaining a slump range of 4-7 to permit the solid placement of the Paver Tile in the wet cement.
- B. The concrete shall be poured and finished level, true and smooth to the required dimensions prior to the placement of the tile.
- C. Place the tile 6 – 8 inches from the curb line. Working in a grid pattern, tamp the tile into the wet concrete using a rubber mallet and a scrap piece of wood. Continue this process until all of the air has been released, and the tile surface is flush with the surrounding area.



IMPORTANT: You should always avoid striking the surface of the tile directly.

- D. Following the placement, the tile elevation should be checked to the adjacent surface with a straight edge. The tile elevation should be consistent with the Contract Drawings and Specifications. Any required adjustments must be made prior to the time when the concrete begins to set.
- E. When you are confident that the tile is in place, and no further adjustments are needed, place a cinder block on both ends to hold the tile in place while the concrete sets.
- F. During and after the tile installation, as well as the concrete curing stage, no walking or external forces can be placed on the tile. The area must be protected from pedestrian traffic until concrete is cured. The surface will be ready for pedestrian traffic within 1 – 2 hours.
- G. Be sure to clean all debris from the face of the tile before concrete can cure.

PRODUCT SIZES 24"x36", 24"x48", 24"x60", 36"x48", 36"x60"

APPLICATION Fresh Pour Concrete Ramps or Platforms